SpeedoHealer

Supplementary Manual



Suzuki GSX-R1000 2007-2008 (SH-V4 + SH-S01)

Remove the main and passanger seat.



Remove the black covers from the fuel tank.



Lift up or remove the fuel tank.



SpeedoHealer

Supplementary Manual



Suzuki GSX-R1000 2007-2008 (SH-V4 + SH-S01)

Plug the SpeedoHealer connectors in-line with the vehicle speed sensor connectors.

(Black, 3-pole connectors at the left side below the fuel tank)



Typical position for the remote button.



Typical position for the SpeedoHealer.

Secure the unit properly.

